

Configuration lecteur SYMBOL LS4208 / LS2208



PARAMETRES PAR DEFAUT



MONOTRAME



OPTIONS DE LECTURE



<DATA><SUFFIX>



ENTER



Windows FRANCAIS



Enable Caps Lock Override



Scan Options



<PREFIX> <DATA> <SUFFIX>



Enter



Scan Prefix



5



0



1



2